

Teleco 12 kanal håndsender TXR433A12

Venstre knap	Display	Højre knap
CH 1	1	CH 2
CH 1	2	CH 2
CH 1	3	CH 2
CH 3	4	CH 4
CH 3	5	CH 4
CH 3	6	CH 4